

---

# REDIEN<sup>TM</sup>

## Japan

:RN-8831



## Instructions

### **Read all instruction before using**

The instruction manual for the hair iron.  
Thank you for purchase of the hair iron.


## Function

- 1.Curling hair.
- 2.Compress and correct the hair.
- 3.LED light for power supply indication.
- 4.Protect hair and keep color.
- 5.Plating curling iron

## Character

- 1.Easy to operate.
- 2.Quickly heat and keep temperature changeless while working.
- 3.Make your hair shiny and comfortable.
- 4.Design for housing and professional use.

## Specification

- 
1. Insert the power plug into the power outlet.
  2. Slide the switch on to the 'ON' position. Please make sure that the iron is rested on a smooth flat surface.
  3. The power light will be on when it turns on the power switch, then it heat up.
  4. For optimum styling temperature allow iron to heat for 5 minutes before using as the iron will continue to gain heat until it reaches the constant temperature.
  5. Preparing your hair for curling. Once you have washed your hair, dry it well. Then use the curling iron to fashion your hair. If you have never used a curling iron before, please practice without heating first.
  6. Please turn off the power switch and unplug it after using.

## Important safeguards

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

### **Warning**

1. Do not immerse the iron in water.
2. Do not use the iron on wet hair.
3. Do not touch the plates while hot.
4. Do not plastic or heat sensitive surfaces.
5. Keep away from children.

6. Keep the cord away from heated surfaces.
7. Do not operate any appliance with a damaged plug or cord if it has been damaged in any manner.
8. The iron is only intended for use as a hair styling iron and only with products specifically designed for use with a heated styling iron.
9. This appliance intended for housing use only. Use with the rated voltage only.
10. Please do not attempt to dismantle the iron. There are no serviceable parts inside.
11. Do not use while bathing and keep away from water while using the appliance.
12. Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
13. Appliance is not to be used by children or persons with reduced physical, sensory or mental Capabilities, or lack of experience and knowledge, Unless they have been given supervision or instruction.
14. Children being supervised not to play with appliance.



## Note

1. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
2. To avoid scald, do not touch the high temperature area when the appliance has been in use.